

Keep things within reach

Samsung Galaxy S7 & S7 Edge News

Monday, March 14 2015



Holders for Samsung Galaxy S7 & S7 Edge

Choose a holder from our ranges for the Samsung Galaxy S7 or S7 Edge to keep your device securely in place. Holders are available with different characteristics; passive holder for a firm fit, and active holders for charging. The active holders are available with a cig-plug cable, USB-cable with cigplug adapter, or for fixed installation.

All holders are equipped with a tilt swivel so you can easily adjust the angle of your device for better viewing. You can switch between portrait and landscape mode just by turning the holder into desired position.

Features:

- Passive holder
- Active holder with cig-plug.
- Active holder with USB-cable.
- Active holder for fixed installation.
- With tilt swivel.
- Provides a perfect fit.
- Made of black plastic
- Made in Sweden

Galaxy S7	Galaxy S7 Edge	Product
511863	511866	Passive holder.
512863	512866	Active holder with cig-plug cable.
521863	521866	Active holder with USB-cable with cig-plug adapter.
513863	513866	Active holder for fixed installation.
944011	944011	Charging cable.

